
REEL REPAIR BULLETIN #7

THE BEST IN RODS - REELS - LINES - LURES

AUTOMATIC FLY REELS





Disassembly and Assembly Instructions

- 1. Press brake lever to release all spring tension.
- Remove staff screw.
- Remove drive spring cap assembly by turning counter-clockwise and pulling slowly and slightly. (This method will hold spring in place.)
- Gear plate assembly is next removed by gently prying up with a screw driver or coin inserted in opening near base of brake lever.
- 5. Lift out spool assembly. To accomplish this on the No. 1180 reel, the brake lever must first be removed by lifting the brake lever spring off its pin which will free the lever.

PART NAME	PART NUMBER AND PRICE									
	1130	PRICE	1140	PRICE	1150	PRICE	1180	PRICE	1190	PRICE
Upper Staff Screw Drive Spring Cap Assembly Ratchet Coil Case Ring Ratchet Coil Ratchet Release Ring Ratchet Coil Case Drive Gear Assembly Intermediate Gear Assembly Intermediate Gear Assembly Drive Spring Line Protector Rivets Line Protector Spool Assembly Drive Spring Line Protector Spool Staff Frame Assembly Brake Lever Assembly Safety Button Safety Button Safety Stop Safety Button Tension Washer	AA-19 B1493K AD-5 A-15 E2424 A-13, E2763 A-16 B2762K A-14 AB-3 B1443 A-8 B1584 AB-7 AD-17 ≠ A3734L AA-4 —E1704 A-12 B260K AA-11 NE1568 AG-18 E2555 AE-6 A-2 A-1 E2447	\$.10 1.35 .02 .20 .35 .65 .20 .55 2.30 1.50 .03 .40 .25 3.95 .65	A-12 B260K AB-11 NE1569	1.35 .02 3.20 .35 .65 .20 .55 2.30 1.40	AA-19 AC-5 A-15 A-13 A-16 AA-14 AB-3 A-8 AB-7 AE-17 AA-4 A-12 AB-11 AH-18 AD-6 A-2 A-1 A-2 A-1 A-2 A-1 A-2 A-1 A-2 A-1 A-2 A-1 A-2 A-2 A-2 A-2 A-2 A-2 A-2 A-2 A-2 A-2	\$.10 1.35 .02 .20 .35 .65 .20 .55 .230 1.40 1.50 .03 .45 .25 4.30 .65 .15	AA-19 AE-5 A-15 A-16 AB-14 AB-3 A-8 AC-7 AE-17 AA-4 A-12 AB-11 AH-18 AH-6A AA-2 A-1	\$.10 1.60 .02 .20 .35 .65 .20 .55 1.70 1.40 1.50 .03 .45 .25 2.50	AA-19 B1493K AE-5 A-15 E2424 A-13 A2763 A-16 B2762K AB-14 AB-3 B1443 A-8 B1584 AC-7 AE-17 A3735L AA-4 E1704 A-12 B260K AB-11 NE1569 AH-18 E2556 AC-6 AB-2 A-1 E2447	\$.10 1.60 .02 .20 .35 .65 1.70 1.40 1.50 .03 .45 .25 4.10 .65

1180

Numbers shown in red common to both South Bend and Shakespeare.

NOTE: When ordering parts, give reel part name, reel number and model.